

# 業務区域図

その1

凡	例
一定幅員	不定幅員
3.00m	4.00m
4.00m	5.00m
5.00m	6.00m
6.00m	7.00m
7.00m	8.00m
8.00m	9.00m
9.00m	10.00m
10.00m	11.00m
11.00m	12.00m
12.00m	13.00m
13.00m	14.00m
14.00m	15.00m
15.00m	16.00m
16.00m	17.00m
17.00m	18.00m
18.00m	19.00m
19.00m	20.00m
20.00m	21.00m
21.00m	22.00m
22.00m	23.00m
23.00m	24.00m
24.00m	25.00m
25.00m	26.00m
26.00m	27.00m
27.00m	28.00m
28.00m	29.00m
29.00m	30.00m
30.00m	31.00m
31.00m	32.00m
32.00m	33.00m
33.00m	34.00m
34.00m	35.00m
35.00m	36.00m
36.00m	37.00m
37.00m	38.00m
38.00m	39.00m
39.00m	40.00m
40.00m	41.00m
41.00m	42.00m
42.00m	43.00m
43.00m	44.00m
44.00m	45.00m
45.00m	46.00m
46.00m	47.00m
47.00m	48.00m
48.00m	49.00m
49.00m	50.00m
50.00m	51.00m
51.00m	52.00m
52.00m	53.00m
53.00m	54.00m
54.00m	55.00m
55.00m	56.00m
56.00m	57.00m
57.00m	58.00m
58.00m	59.00m
59.00m	60.00m
60.00m	61.00m
61.00m	62.00m
62.00m	63.00m
63.00m	64.00m
64.00m	65.00m
65.00m	66.00m
66.00m	67.00m
67.00m	68.00m
68.00m	69.00m
69.00m	70.00m
70.00m	71.00m
71.00m	72.00m
72.00m	73.00m
73.00m	74.00m
74.00m	75.00m
75.00m	76.00m
76.00m	77.00m
77.00m	78.00m
78.00m	79.00m
79.00m	80.00m
80.00m	81.00m
81.00m	82.00m
82.00m	83.00m
83.00m	84.00m
84.00m	85.00m
85.00m	86.00m
86.00m	87.00m
87.00m	88.00m
88.00m	89.00m
89.00m	90.00m
90.00m	91.00m
91.00m	92.00m
92.00m	93.00m
93.00m	94.00m
94.00m	95.00m
95.00m	96.00m
96.00m	97.00m
97.00m	98.00m
98.00m	99.00m
99.00m	100.00m



南地区

西地区

東地区

鉄西・幌北  
南地区

新川西

新琴似町

屯田町

西茨戸

東茨戸

屯田

篠路町篠路

新琴似

篠路

あいの里

新川

太平

幌北

百合が原

南あいの里

北・藻生

篠路町上篠路

篠路町拓北

篠路町福移